

COMSATS UNIVERSITY ISLAMABAD, WAH CAMPUS



Group-Members:

FA21-BCS-066

Hussain Ali

FA21-BCS-080

Ali Shan

Section:

BCS-8A

Project-Title:

Real-time Weapon Detection

Table:

Topic	Page No.
Learning Outcomes	3
Interface	4
Video	5
Model Training	5-7
Model Validation	8-16
Flow Chart	17
Activity Diagram	18
Use-Case Diagram	19
Sequence Diagram	20
State Diagram	21
Component Diagram	22
Deployment Diagram	23

Learning Outcomes:

HUSSAIN ALI

(FA21-BCS-066):

Dataset Finding

Model Information

Flow-Diagrams

ALI SHAN


(FA21-BCS-080):

Interface

Model Training

Model Validation

Interface:



Video:



detected_pistols (2).mp4

Code link:

<https://colab.research.google.com/drive/1qSBC3GYZnbK>

Model Training

```
[1] from IPython.display import clear_output
|pip install ultralytics ultralytics-hub
|pip install roboflow
|pip install torch torchvision torchaudio --index-url https://download.pytorch.org/whl/cu118
|pip install opencv-python
clear_output()

from roboflow import RoboFlow
rf = RoboFlow(api_key="wGrQSC42QTpPwK44z31c")
project = rf.workspace("concealed-weapon-detection").project("thermal-pistol-jw5pm")
version = project.version(1)
dataset = version.download("yolov11")

loading RoboFlow workspace...
loading RoboFlow project...
Downloading Dataset Version Zip in Thermal-pistol-1 to yolov11:: 100%|██████████| 3686/3686 [00:00<00:00, 10205.32it/s]
Extracting Dataset Version Zip to Thermal-pistol-1 in yolov11:: 100%|██████████| 336/336 [00:00<00:00, 9951.04it/s]

[ ] from ultralytics import YOLO

# Option 2: Load a pretrained model (recommended)
model = YOLO("yolo11n.pt") # Ensure "yolo11n.pt" exists in your working directory
```

2s completed at 6:22 AM

Downloading Dataset Version Zip in Thermal-pistol-1 to yolov11:: 100% [██████████] 3686/3686 [00:00:00:00, 10205.32it/s]

Extracting Dataset Version Zip to Thermal-pistol-1 in yolov11:: 100% [██████████] 336/336 [00:00:00:00, 9951.04it/s]

```
[ ] from ultralytics import YOLO

# Option 2: Load a pretrained model (recommended)
model = YOLO("yolo11n.pt") # Ensure "yolo11n.pt" exists in your working directory
```

Creating new Ultralytics Settings v0.0.6 file ☒
View Ultralytics Settings with 'yolo settings' or at '/root/.config/Ultralytics/settings.json'
Update Settings with 'yolo settings key=value', i.e. 'yolo settings runs_dir=path/to/dir'. For help see <https://docs.ultralytics.com/quickstart/#ultralytics-se>
Downloading <https://github.com/ultralytics/assets/releases/download/v8.3.0/yolo11n.pt> to 'yolo11n.pt'...
100% [██████████] 5.35M/5.35M [00:00:00:00, 96.5MB/s]

```
▶ # Load an image (replace with your image path)
image_path = '/content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg'

# Run inference
results = model(image_path)

# Display results
results[0].show() # Access the first element in the list and call .show()
```

image 1/1 /content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg: 640x640 (no detections), 12.5ms
Speed: 3.6ms preprocess, 12.5ms inference, 107.8ms postprocess per image at shape (1, 3, 640, 640)
✓ 2s completed at 6:22 AM

Q Commands + Code + Text Copy to Drive

image 1/1 /content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg: 640x640 (no detections), 12.5ms
Speed: 3.6ms preprocess, 12.5ms inference, 107.8ms postprocess per image at shape (1, 3, 640, 640)



✓ 2s completed at 6:22 AM

concealWeaponDetection.ipynb ⭐ Cannot save changes

File Edit View Insert Runtime Tools Help

Q Commands + Code + Text Copy to Drive

```
from ultralytics import YOLO

# Load the model
model = YOLO("yolo11n.pt") # Replace with your model path


# Load an image (replace with your image path)
image_path = '/content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg'

# Run inference with a lower confidence threshold
results = model(image_path, conf=0.25)

# Display results
results[0].show() # Show the image with detections

# Save the results
results[0].save('output_image.jpg') # Save the output image

# Access detection details
for result in results:
    boxes = result.boxes # Bounding boxes
    classes = boxes.cls # Class IDs
    confidences = boxes.conf # Confidence scores
    print("Classes:", classes)
    print("Confidences:", confidences)
```



```
from ultralytics import YOLO

# Load the pretrained model
model = YOLO("yolo11n.pt") # Replace with the path to your pretrained model

# Fine-tune the model on your custom dataset
results = model.train(
    data="/content/Thermal-pistol-1/data.yaml", # Path to your dataset configuration file
    epochs=100, # Number of training epochs
    imgsz=640, # Image size
    batch=16, # Batch size
    device=0, # Use GPU (set device=0 for GPU, device='cpu' for CPU)
    workers=2, # Number of data loading workers
    lr=0.01, # Initial learning rate
    weight_decay=0.0005, # Weight decay
    optimizer="SGD", # Optimizer (SGD, Adam, etc.)
    name="yolo11n_finetuned" # Name of the training run
)

# Validate the model on the validation set
metrics = model.val() # Validate the model
print(metrics.box.map) # Print mAP (mean Average Precision)
```

✓ 13s completed at 6:24 AM

● X

Model Validation

```
# Validate the model on the validation set
metrics = model.val() # Validate the model
print(metrics.box_map) # Print mAP (mean Average Precision)
```

Ultralytics 8.3.95 Python-3.11.11 torch-2.6.0+cu124 CUDA:0 (Tesla T4, 15095MiB)
engine/trainer: task=detect, mode=train, model=yolo11n.pt, data=/content/Thermal-pistol-1/data.yaml, epochs=100, time=None, patience=100, batch=16, imgs=640
Downloading https://ultralytics.com/assets/Arial.ttf to '/root/.config/Ultralytics/Arial.ttf'...
100% [██████████] 755k/755k [00:00<00:00, 22.4MB/s]
Overriding model.yaml nc=80 with nc=1

	from	n	params	module	arguments
0	-1	1	464	ultralytics.nn.modules.conv.Conv	[3, 16, 3, 2]
1	-1	1	4672	ultralytics.nn.modules.conv.Conv	[16, 32, 3, 2]
2	-1	1	6640	ultralytics.nn.modules.block.C3k2	[32, 64, 1, False, 0.25]
3	-1	1	36992	ultralytics.nn.modules.conv.Conv	[64, 64, 3, 2]
4	-1	1	26080	ultralytics.nn.modules.block.C3k2	[64, 128, 1, False, 0.25]
5	-1	1	147712	ultralytics.nn.modules.conv.Conv	[128, 128, 3, 2]
6	-1	1	87040	ultralytics.nn.modules.block.C3k2	[128, 128, 1, True]
7	-1	1	295424	ultralytics.nn.modules.conv.Conv	[128, 256, 3, 2]
8	-1	1	346112	ultralytics.nn.modules.block.C3k2	[256, 256, 1, True]
9	-1	1	164608	ultralytics.nn.modules.block.SPPF	[256, 256, 5]
10	-1	1	249728	ultralytics.nn.modules.block.C2PSA	[256, 256, 1]
11	-1	1	0	torch.nn.modules.upsampling.Upsample	[None, 2, 'nearest']
12	[-1, 6]	1	0	ultralytics.nn.modules.conv.Concat	[1]
13	-1	1	111296	ultralytics.nn.modules.block.C3k2	[384, 128, 1, False]
14	-1	1	0	torch.nn.modules.upsampling.Upsample	[None, 2, 'nearest']
15	[-1, 4]	1	0	ultralytics.nn.modules.conv.Concat	[1]
16	-1	1	32096	ultralytics.nn.modules.block.C3k2	[256, 64, 1, False]
17	-1	1	36992	ultralytics.nn.modules.conv.Conv	[64, 64, 3, 2]
18	[-1, 13]	1	0	ultralytics.nn.modules.conv.Concat	[1]

✓ 13s completed at 6:24 AM

```
# Validate the model on the validation set
metrics = model.val() # Validate the model
print(metrics.box_map) # Print mAP (mean Average Precision)
```

YOLO11n summary: 181 layers, 2,590,035 parameters, 2,590,019 gradients, 6.4 GFLOPs

Transferred 448/499 items from pretrained weights
TensorBoard: Start with 'tensorboard --logdir runs/detect/yolo11n_finetuned', view at <http://localhost:6006/>
Freezing layer 'model.23.dfl.conv.weight'
AMP: running Automatic Mixed Precision (AMP) checks...
AMP: checks passed ✓
train: Scanning /content/Thermal-pistol-1/train/labels... 114 images, 1 backgrounds, 0 corrupt: 100% [██████████] 114/114 [00:00<00:00, 2260.26it/s] train: New
albumnations: Blur(p=0.01, blur_limit=(3, 7)), MedianBlur(p=0.01, blur_limit=(3, 7)), ToGray(p=0.01, num_output_channels=3, method='weighted_average'), CLA
val: Scanning /content/Thermal-pistol-1/valid/labels... 32 images, 0 backgrounds, 0 corrupt: 100% [██████████] 32/32 [00:00<00:00, 1492.00it/s] val: New cache

Plotting labels to runs/detect/yolo11n_finetuned/labels.jpg...
optimizer: SGD(lr=0.01, momentum=0.937) with parameter groups 81 weight(decay=0.0), 88 weight(decay=0.0005), 87 bias(decay=0.0)
TensorBoard: model graph visualization added ✓
Image sizes 640 train, 640 val
Using 2 dataloader workers
Logging results to runs/detect/yolo11n_finetuned
Starting training for 100 epochs...

Epoch	GPU_mem	box_loss	cls_loss	dfl_loss	Instances	Size
1/100	2.29G	2.234	5.03	1.969	7	640: 100% [██████████] 8/8 [00:04<00:00, 1.96it/s]

✓ 13s completed at 6:24 AM

Validate the model on the validation set
metrics = model.val() # Validate the model
print(metrics.box_map) # Print mAP (mean Average Precision)

<

```
100 epochs completed in 0.073 hours.
Optimizer stripped from runs/detect/yolo11n_finetuned/weights/last.pt, 5.5MB
Optimizer stripped from runs/detect/yolo11n_finetuned/weights/best.pt, 5.5MB

Validating runs/detect/yolo11n_finetuned/weights/best.pt...
Ultralytics 8.3.95 Python-3.11.11 torch-2.6.0+cu124 CUDA:0 (Tesla T4, 15095MiB)
YOLO11n summary (fused): 100 layers, 2,582,347 parameters, 0 gradients, 6.3 GFLOPs
Class Images Instances Box(P) R mAP50 mAP50-95): 100% 1/1 [00:00:00:00, 3.61it/s]
all 32 32 0.995 1 0.995 0.731
Speed: 0.2ms preprocess, 2.2ms inference, 0.0ms loss, 1.0ms postprocess per image
Results saved to runs/detect/yolo11n_finetuned
Ultralytics 8.3.95 Python-3.11.11 torch-2.6.0+cu124 CUDA:0 (Tesla T4, 15095MiB)
YOLO11n summary (fused): 100 layers, 2,582,347 parameters, 0 gradients, 6.3 GFLOPs
val: Scanning /content/Thermal-pistol-1/valid/labels.cache... 32 images, 0 backgrounds, 0 corrupt: 100% 32/32 [00:00:?, ?it/s]
Class Images Instances Box(P) R mAP50 mAP50-95): 100% 2/2 [00:01:00:00, 1.94it/s]
all 32 32 0.995 1 0.995 0.736
Speed: 6.8ms preprocess, 10.2ms inference, 0.0ms loss, 1.9ms postprocess per image
Results saved to runs/detect/yolo11n_finetuned2
0.7364563072819064
```

```
# Test on an image
results = model("/content/Thermal-pistol-1/test/images/0024.jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg")
results[0].show() # Display the results
```

image 1/1 /content/Thermal-pistol-1/test/images/0024.jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg: 640x640 1 Gun, 12.6ms

✓ 13s completed at 6:24AM

```
# Test on an image
results = model("/content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg")
results[0].show() # Display the results
```

image 1/1 /content/Thermal-pistol-1/test/images/0024_jpg.rf.9f7fac4588e9e28074e4b652448d7ebb.jpg: 640x640 1 Gun, 12.6ms
Speed: 3.8ms preprocess, 12.6ms inference, 2.3ms postprocess per image at shape (1, 3, 640, 640)



Gun 0.83

✓ 13s completed at 6:24 AM

```
[ ] from google.colab import files
files.download("/content/runs/detect/yolo11n_finetuned/weights/best.pt")
```

```
import os
import time
from ultralytics import YOLO

# Load the fine-tuned model
model = YOLO("/content/runs/detect/yolo11n_finetuned/weights/best.pt") # Replace with your fine-tuned model path

# Directory containing test images
test_images_dir = "/content/Thermal-pistol-1/test/images"

# Iterate through all images in the directory
for image_name in os.listdir(test_images_dir):
    # Construct the full path to the image
    image_path = os.path.join(test_images_dir, image_name)

    # Run inference on the image
    results = model(image_path)


    # Display the results
    results[0].show() # Show the image with detections
```


✓ 13s completed at 6:24 AM

Q Commands + Code + Text Copy to Drive



✓ 13s completed at 6:24 AM





```

from ultralytics import YOLO
import matplotlib.pyplot as plt

# Load trained model
model = YOLO('/content/runs/detect/yolo11n_finetuned/weights/best.pt')

# Validate model
metrics = model.val(
    data='/content/Thermal-pistol-1/data.yaml',
    split='test', # Use test split for final evaluation
    plots=True
)

# Print key metrics
print(f"mAP50-95: {metrics.box.map:.4f}")
print(f"Precision: {metrics.box.mp:.4f}")
print(f"Recall: {metrics.box.mr:.4f}")
print(f"F1 Score: {2 * (metrics.box.mp * metrics.box.mr) / (metrics.box.mp + metrics.box.mr):.4f}")

# Plot confusion matrix
confusion_matrix = plt.imread('/content/runs/detect/val/confusion_matrix.png')
plt.figure(figsize=(10, 8))
plt.imshow(confusion_matrix)
plt.axis('off')
plt.title('Confusion Matrix')
plt.show()

```

0s completed at 6:35AM

```

import yaml
import cv2
import numpy as np
from PIL import Image
from ultralytics.utils.plotting import plot_images

# Load dataset config
with open('/content/Thermal-pistol-1/data.yaml') as f:
    data = yaml.safe_load(f)

# Class distribution visualization
class_counts = []
for split in ['train', 'valid', 'test']:
    label_dir = f'/content/Thermal-pistol-1/{split}/labels'
    counts = np.zeros(data['nc'])
    for label_file in os.listdir(label_dir):
        with open(os.path.join(label_dir, label_file)) as f:
            for line in f:
                class_id = int(line.split()[0])
                counts[class_id] += 1
    class_counts.append(counts)

plt.figure(figsize=(15, 5))
for i, split in enumerate(['Train', 'Validation', 'Test']):
    plt.subplot(1, 3, i+1)
    plt.bar(range(data['nc']), class_counts[i])
    plt.title(f'{split} Class Distribution')
    plt.xlabel('Class ID')

```

0s completed at 6:35AM

```


plt.title(f'{split} Class Distribution')
plt.xlabel('Class ID')
plt.ylabel('Count')
plt.tight_layout()
plt.show()

# Bounding box size distribution
box_sizes = []
for split in ['train']:
    label_dir = f'/content/Thermal-pistol-1/{split}/labels'
    for label_file in os.listdir(label_dir):
        with open(os.path.join(label_dir, label_file)) as f:
            for line in f:
                _, x, y, w, h = map(float, line.split())
                box_sizes.append((w, h))


w, h = zip(*box_sizes)
plt.figure(figsize=(10, 5))
plt.subplot(1, 2, 1)
plt.hist(w, bins=50)
plt.title('Normalized Width Distribution')
plt.subplot(1, 2, 2)
plt.hist(h, bins=50)
plt.title('Normalized Height Distribution')
plt.tight_layout()
plt.show()
# Sample training images with labels

```

0s completed at 6:35 AM



0s completed at 6:35 AM



```
# Training metrics visualization
training_metrics = plt.imread('/content/runs/detect/yolo11n_finetuned/results.png')
plt.figure(figsize=(12, 6))
plt.imshow(training_metrics)
plt.axis('off')
plt.title('Training Metrics')
plt.show()

# Prediction visualization on test set
test_images = [os.path.join('/content/Thermal-pistol-1/test/images', f)
               for f in os.listdir('/content/Thermal-pistol-1/test/images')[:6]]


fig, axes = plt.subplots(2, 3, figsize=(20, 12))
for ax, img_path in zip(axes.flat, test_images):
    results = model(img_path)
    ax.imshow(results[0].plot())
    ax.axis('off')
plt.tight_layout()
plt.show()

# Precision-Recall curve
pr_curve = plt.imread('/content/runs/detect/val/R_curve.png')
plt.figure(figsize=(10, 8))
plt.imshow(pr_curve)
plt.axis('off')
plt.title('Precision-Recall Curve')
plt.show()
```


0s completed at 6:35 AM

Flow-Diagrams


1. Flow-chart




2. Activity-Diagram




3. Use-Case Diagram




4. Sequence-Diagram




5. State-Diagram



6. Component-Diagram



7. Deployment-Diagram



*****THE END *****